





Locate the plug that connects to the power supply under the counter and re-seat it in the socket.

Check for LED's to light-up on the PCB and wait 3-5 minutes for the Poursteady to completely re-boot.





