

Pro Tips and Suggestions During Initial Start-Up of XGi Grinders

- **READ THE MANUAL AND START UP INSTRUCTIONS** - Scan QR code or follow the link below to read manual and initial start up instructions;
 - chrome-extension://efaidnbmnnnibpcajpcglclefindmkaj/https://ep-shopify.s3.amazonaws.com/related-documents/fiorenzato/f64exgi/f64e-xgi-manual.pdf
- **PREPARE YOUR WORK STATION** - During initial start up the work station should be free from vibration and other environmental impacts such as fans or strong direct airflows.
- **COFFEE REQUIRED TO DIAL IN** - During initial start up, the hopper should be full. Expect to use 150-300 grams of coffee to get dialed in.
- **GRIND ADJUSTMENT RING** - During initial start up the grind adjustment ring should be set at number 2.
- **GET A HELPING HAND** - When adjusting the degree of grinding, you will need a helping hand to turn the adjustment disk while you dial in your preferred grind size.
- **TRY AGAIN** - IF during initial start up you are not able to complete set up, you will be prompted to restart the start up procedure. Please double check your workstation to ensure there are no vibrations or environmental impacts like a fan blowing on the grinder.
- **GIVE US A CALL** - IF you are not able to complete the set up on the second attempt, you will be prompted to restart the initial start up procedure. Please stop and call customer support @ (800) 459-5594. You may need to recalibrate the scale to complete set up.